

注意:
本手册描述的产品及其附件的某些特征和功能,仅供参考。
十度数码科技保留随时修改本手册中任何信息的权利,无需进行任何提前通知且不承担任何责任。

无担保声明:
本手册中的内容,除非适用法律要求,十度数码科技对本手册中的所有内容不提供任何明示或暗示的保证。
在法律允许的范围内,十度数码科技在任何情况下,都不对因使用本手册相关内容而产生的任何特殊的、附带的、间接的、继发性的损害进行赔偿,也不对任何利润、数据、商誉或预期的损失进行赔偿。

进出口管制:
若需将此产品手册中描述的产品出口、再出口、或者进口,您应遵守适用的进出口管制法律法规。

深圳市十度数码科技有限公司 地址:深圳市福田区新洲工业区金田路4号栋4楼404室
Shenzhen SHIDU Digital Co., Ltd. 电话:00755-21635866 传真:00755-23105099
邮编:518040
注册号码:4008 939 488
官方网站:WWW.10SHIDU.COM

本手册所有产品图片及文字内容均已详细核对,如出现印刷错误,本公司不承担任何此产生的后果,产品图片及详细参数数据以实物为准。
SHIDU十度数码科技(CO)保留所有权利,受知识产权保护,未经授权,不得转载、复制或仿造。
本公司保留对产品变更及改进的权利,恕不另行通知,在法律允许范围内,最终解释权归深圳市十度数码科技有限公司所有。

Function Illustration:

1.Power switch / volume control: Pull the wheeled to "ON" to turn on the amplifier with a sound of "crack". And pull to "ON" continuously to increase volume; pull to "OFF" continuously to decrease volume till turn off.

2.Mode: Short press "M" key to select a working mode: Bluetooth mode, USB / TF card mode (After insert the USB flash drive / TF card), FM mode.

3.Previous: Long press "M" for fast backward; Short press to switch to the previous music.

4.Play/Pause: Short press "M" to pause in music mode, and short press again to play. Long press "M" to switch to single loop, long press "M" again to switch to all loop.

5.Next: Long press "M" for fast forward, short press switch to next music.

6.MIC slot: This machine supports wired microphone input.

7.Audio input: Connecting amplifier to external audio device (computer/cellphone/MP3/MP4) via AUX cable, amplifier will play music in above devices when LCD screen show "LINE".

8.FM antenna

9.Digital display screen

10.DC 5V charging port

11.Micro SD slot: Insert the Micro SD card to play mp3. It is compatible with most brands, the maximum capacity is 32GB.

12.USB flash drive slot: Insert the USB flash drive to play mp3. It is compatible with most brands, the maximum capacity is 32GB.

Note: It may be unreadable when the file is large or complex.

Amplification function:
Pull the wheeled to "ON" and with a sound of "crack", the amplifier turn on. Plug standard 3.5mm wired mic into MIC slot, ensure that the MIC don't point at the amplifier, this will eliminate any annoyance associated with howling. For ensure better amplification, aim at the headset MIC capsule when speaking, and keep the distance between the voice amplifier and the MIC more than 60 cm to avoid howling.

Simply tucking the speaker around waist, and mounting headphone over head can help achieve the required distance.

Bluetooth 5.0 Function:

Step 1: Turn on voice amplifier and press "M" key to select Bluetooth mode, and "BT" will keep flashing on screen, which indicates the bluetooth is waiting for connection.

Step 2: Enter into "Setting" of your phone and turn on Bluetooth, then search "S268" and connect, connecting successfully with sound "Bluetooth is connected".

Step 3: When playing music, please keep close to the amplifier to keep the signal stable. If the distance is too far (more than 10 m), the Bluetooth will be disconnected.

FM radio function:

1.Turn on voice amplifier and pull up antenna; short press "M" key to switch to FM mode and the LCD show FM frequency;

2.Long press "M" enter into automatic channels searching; after searched successfully, the amplifier will save the channels automatically;

3.Short press "M" or "M" to choose the saved channels to play.

Charging for Voice Amplifier:
When charging, please use DC 5V charger connect with charging cable, one end connect to the DC 5V port of the amplifier, the other end connect with the power supply AC110-220V. The battery icon on the screen keep flashing during charging and stop flashing when fully charged. The speaker will stop all functions while charging.

Notes:

A.The battery icon continuous flashing when it is low battery, please recharge it timely. It takes 3-5 hours to charge.

B.Suggest fully charged before your first use for the best effect.

C.This speaker is suitable for charging with all kinds of mobile phone adapter. Please unplug the charging socket promptly after full charged and disconnect the power supply.

Caution:

1.Aim at the head-worn MIC capsule when speaking and keep the distance between voice amplifier and MIC longer than 60cm avoid howling.

2.Recharge timely when battery is lack of power.

3.The amplifier should be kept in dry and ventilated area, rain, water, thump should be avoided.

4.Original accessories are suggested if they need to be replaced.

5.Non-professional technician is not allowed to dismantle or repair the product; please contact the local agent if there is any question or service requirement.

SHIDU Guarantee:
100% SHIDU Guaranteed Product Satisfaction. We promise 1 year warranty. If you have any questions, please feel free to contact us, we will try our best to provide you the best service, www.10shidu.com Email: service@10shidu.com

SHIDU

扩音器

使用说明书

USER MANUAL

关注十度微信公众号
回复型号"S268"
获取设备使用教程

安全警告:

1. 请勿将产品及配件靠近热源或任何过热的环境中。

2. 请勿将产品及配件接触水及湿气,不要在最近水的地方使用本设备,也不要将产品浸入任何液体中,避免产品及配件受到水滴或水溅。

3. 请勿自行打开或任意拆解。维修电池组件,如果电池更换不当会有爆炸危险,严禁将电池投入水、火中或靠近任何过热的环境中。

4. 本产品由外接电源适配器(5V 1.5A 电源)充电后使用,充电后可方便的通过拔掉电源适配器插头断开电网电源。

5. 当用户暂不使用本产品时,请将产品电源开关拨动至关闭状态关闭电源(参见产品操作示意图),避免电池电量的流失。

6. 当禁止使用无线设备或设备的使用会引起电子设备的干扰与安全隐患时,请关闭本产品。

7. 在易燃易爆区域,请关闭本产品,并遵守相关标示说明,以免引起爆炸或火灾。易燃易爆区域包括但不限于:加油站、易燃或化工制品运输及储存设施、有爆炸危险标志的区域,有"关掉双向无线电设备"标志的区域。

8. 乘坐飞机时,请遵守航空公司有关规定和条例,在飞机起飞前关闭本产品,以免造成安全隐患。

9. 若使用电源适配器供电,应购买配套使用获得CCC认证并满足要求的电源适配器。

产品特点:

- 采用双磁喇叭,声音穿透力强、覆盖面积广
- 采用十度原声扩音电声系统
- 支持AUX音频输入,可作为电脑、iPad、iPhone音箱
- MP3音频解码技术;支持TF卡/U盘播放功能
- 支持曲目显示,人性化设计
- 支持FM收音功能
- 10W功率,1100mAh聚合物电池

主机技术参数:

输出功率:	10W	频率响应:	90Hz-18KHz
喇叭阻抗:	4Ω	工作温度:	-10°C-45°C
充电电压:	DC5V=1.5A	充电时间:	3-5小时

产品操作示意图:

1. 电源开关/音量调节: 将接轮开关拨至"ON"方向,当听到"咔"的一声,表示已经开机;同时拨动至"ON"方向为音量加,拨至"OFF"方向为音量减;将接轮开关拨至"OFF"位置时,当听到"咔"的一声,表示机器关机。

2. 模式切换: 在插入U盘、TF卡时可短按"M"键来切换需要的工作模式,蓝牙模式、音乐模式、FM模式。

3. 上一曲: 长按"◀"为快退,短按为上一曲。

4. 播放/暂停: 在音乐模式下短按"▶"键为暂停,再次短按为播放;长按"▶"为单曲循环,再次长按"▶"键为全部循环。

5. 下一曲: 长按"▶"为快进,短按为下一曲。

6. MIC 麦克风接口: 本机支持有线麦克风输入。

7. AUX 音频输入: 将机器通过音频线与电脑、手机、MP3、MP4等外接音源连接后,主机屏幕显示"LINE"模式,即可直接释放上述外接音源。

8. FM 收音天线: 收音时拉起天线,在开机状态下短按"M"键调整至FM收音模式,屏幕显示FM电台频率;再长按"▶"键进入自动搜台模式,自动搜台完成后,主机自动保存搜索到的广播频道,可通过短按"◀"或是"▶"键选择储存的播放频道。

9. 数码显示屏

10. DC 5V 充电接口: 当充电时,将DC 5V充电器接头连接主机DC 5V插口,再接驳电源(220V)插座充电。充电时屏幕电池图标将会不停地闪烁,充满电后电池图标变亮。充电时主机将停止其它功能操作。

注意:

a. 在工作时,屏幕电池图标不停的闪烁,表示电力不足,请及时充电。本机充电时间需要 3-5 小时。

b. 第一次使用主机时,电池有小部分电量,为了达到最好的效果,建议先充满电后再使用。

c. 本机适用于各类手机充电器为本机充电,充电完成后可方便的通过拔掉电源适配器插头断开电源。

11. MICRO SD 接口

12. USB PLAYER 卡槽: 仅限数据传输读取U盘数据。

扩音功能说明:
将接轮开关拨至"ON"方向,当听到"咔"的一声,表示已经开机;把标配的麦克风3.5插头插入MIC麦克风接口即可实现扩音。

无线蓝牙操作说明:

第一步:开机按"M"键切换到蓝牙模式,(当主机提示"蓝牙已准备好,正在等待配对",显示屏上显示"bt"在闪烁时为蓝牙模式);

第二步:打开手机,进入手机的"设置"菜单,找到蓝牙功能选项,打开手机的蓝牙功能,点"扫描"按钮,待搜索到"S268"点击"S268"连接即可;同时主机会有提示配对成功。

第三步:连接成功后,即可通过主机播放手机教学教材,培训资料,歌曲播放等。

产品使用注意事项:

1. 为了达到扩音最佳效果,请将喇叭放置端正前方1-2CM处对准喇叭处发音,若有啸叫,可适当调小音量或将机器与喇叭的距离稍微拉开,以相互干扰;

2. 尽量避免频繁拔插麦克风接口,以免造成接口松动而引起接触不良,不可将话筒和音源插错;

3. 为保证锂电池使用寿命,建议使用完再充电,频繁充电将加速电池芯片老化,长时间不用时应每隔两个月充一次电;

4. 因喇叭磁性较强,不可将机器和银行卡等磁性的东西放在一起,以免造成失效而带来不必要的麻烦;

5. 本产品所有配件皆按本机工作需要设计,如需更换配件尽量使用本公司原装配件,以达到最佳工作状态;

6. 本产品在使用过程中可能会轻微发热,这属于正常现象;

7. 请使用防静电软布来清洁擦拭本产品,在清洁本产品时请关闭电源开关,并断开所有外部连接。请勿用化学物质擦拭(如:酒精、苯等化学试剂或有腐蚀性的清洁剂);

8. 请勿摔落、抛掷或奔跑本产品,请勿擅自拆解本产品,否则不能享受本公司的免费维修服务。

常见问题的自我解决:

1. 开关开启,扩音器没有声音
屏幕灯不亮,电源没电,充电器没电,充电线没电。

2. 扩音器有明显啸叫
A. 正确配戴话筒,将麦头记号对准嘴角方向;
B. 音量小时应适当调低音量以免造成啸叫。

产品保修须知:

为了让您更好的享受我公司的各项服务,请仔细阅读以下内容:十度数码科技产品的保修服务由全国各地的十度数码授权技术服务中心负责提供。本产品自销售之日起计保修期和"三包"有效期,在"三包"有效期内,正常状态下使用本产品而发生故障,可依据"三包"规定予以维修、更换、退货。在产品保修期内,可依照本保修条款的内容,在十度数码授权技术服务中心享受免费维修服务(随机附件不在保修范围内)。本品保修期限规定为一年。

在保修期(含"三包"有效期)内以下情况将实施有偿维修服务,同时不享受"三包"服务:

1) 不购买有效保修卡原件和有效发票。

2) 购买产品日期、销售单位名称(盖章有效)等项目未能完整填写或删除保修卡。

3) 由于不可抗拒的自然灾害造成的故障、损伤。

4) 在运输、装卸过程中造成的故障、损伤。

5) 由于未能按照《产品使用说明书》上所写的使用方法和注意事项操作而造成的人为故障。

6) 未经本公司授权人进行的产品拆卸、维修、改装而造成的故障。

需要保修时将请机器与本保修卡(原件)及购机凭证(复印件)一起送往十度数码科技有限公司授权技术服务中心,运输费由用户承担。

产品保修卡

购买产品时,请认真填写此卡,并予以妥善保管。

用户档案

用户姓名	
性别	
通讯地址	
邮编	
联系电话	
购买地点	
购买日期	
品名及规格	
销售单号	
机身编号	
经销商签名	
用户签名	

经销商盖章处

Please read the instruction carefully before using it.

Features:

1.Use dual magnetic speakers, strong sound and wide coverage;

2.Support audio input, can play music by connecting to a computer/phone/ipad;

3.Support TF card/USB flash drive play music;

4.Support Bluetooth 5.0;

5.Support FM radio;

6.10W output power, 1100mAh polymer battery.

Specification:

Output power:	≤10W	Frequency response:	90Hz-18KHz
Impedance:	4Ω	Work temperature:	-10°C-45°C
Charging voltage:	DC 5V=1.5A	Charging time:	3-5 hours