


P12 说明书 128G双铜+风琴折 350*100mm

SD-P12
便携式音箱



5.3


Wireless

说明书



十度音响


产品尺寸图



注意事项

- 请在常温环境中存放以及使用本产品;
- 请勿将本产品暴露在雨中或潮湿环境中;
- 请勿丢掷,避免因跌落造成产品损坏;
- 请勿自行拆解、修理和改造本产品;
- 产品内置锂电池,请勿随意丢弃或置于火中,以免引起危险;
- 电池(电池包或组合电池)不得暴露在诸如日照、火烤或类似过热环境中;
- 消费者使用电源适配器充电,需购买满足当地标准要求电源适配器。

产品示意图 音箱功能按键示意图



1. TWS配对键

2. 上一曲/音量减

3. 暂停/播放

4. 下一曲/音量加

5. 模式切换

6. 开机/关机

7. TF

8. TYPE-C

9. AUX

10. USB

操作示意图 音箱功能按键说明

1.TWS配对键:短按进入重新配对状态;长按一台设备配对键2s,进入TWS配对状态。

2.上一曲/音量减:长按上一曲;短按减音量。

3.暂停/播放/接听/挂断:短按暂停/播放/接听/挂断;来电时,长按拒接。

4.下一曲/音量加:长按下一曲;短按加音量。

5.模式切换:短按模式切换。

6.开机/关机:长按开机/关机。

7.TF:插入TF卡可播放里面的音频文件最大支持32GB。

8.TPYE-C :外接充电线可给设备充电。充电指示灯:充电时红灯常亮,充满红灯熄灭。

9.AUX :可插入直径3.5mm立体头的音频线外接音源设备。

10.USB:外接USB设备可播放设备内的音频文件。

产品参数

产品名称: SD-P12便携式音箱

产品型号: SD-P12

无线版本: 5.3

传输距离: ≥10M

频 响: 65Hz-20kHz

信 噪 比: ≥88dB

额定功率: 15W+5W

电池容量: 7.4V/2000mAh

输 入: 5V=1A/2A

播放时间: 4小时

待机时间: 300天

充电时间: 3小时

产品净重: 640G

产品尺寸: 174x84x70mm

驱动单元: 48x90mm+40.8x 51.2mm

售后服务

本产品有效保修期为自出售之日起一年内,在保修期限内正常适应和维护的情况下,机器本身机件拆料及功能出现问题,发生故障,经查属实,本公司将免费提供维修服务。

产品保修卡


购买产品时,请认真填写此卡,并予以妥善保存。

用户档案

用户姓名	
性别	
通讯地址	
邮编	
联系电话	
购买地点	
购买日期	
品名及规格	
销售单号	
机身编号	
经销商签名	
用户签名	

经销商盖章处

SD-P12
Portable Speaker



5.3


Wireless

Instructions



SHIDU


Product Dimension Drawing



Precautions

- Please store and use this product in a normal temperature environment.
- Do not expose this product to rain or humid environments.
- Do not throw this product to avoid damage caused by falling.
- Do not disassemble, repair or modify this product by yourself.
- This product has a built-in lithium battery. Do not discard it at will or put it in fire to avoid danger.
- Batteries (battery packs or battery assemblies) must not be exposed to environments such as sunlight, fire roasting or similar overheating environments.
- When consumers use a power adapter for charging, they need to purchase a power adapter that meets local standard requirements.

Product introduction
Speaker function button diagram



1. TWS Pairing Key

2. Previous Track/Volume Down

3. Pause/Play

4. Next Track/Volume Up

5. Mode Switch

6. Power On/Off

7. TF

8. TYPE-C

9. AUX

10. USB

Operation Guide
Speaker function button description

1.TWS Pairing Key: Short press to enter the re-pairing state; long press the pairing key of one device for 2 seconds to enter the TWS pairing state.

2.Previous Track/Volume Down: long press for the previous song; Short press to decrease the volume.

3.Pause/Play/Answer/Hang Up: Short press to pause/play/answer/hang up; long press to reject an incoming call.

4.Next Track/Volume Up: long press for the next song; Short press to increase the volume.

5.Mode Switch : Short press to switch modes.

6.Power On/Off: Long press to power on/off.

7.TF : Play music/voice from the TF card, supporting a maximum of 32GB.

8.TPYE-C : Connect an external charging cable to charge the device. Charging indicator light: The red light remains on during charging and goes out when fully charged.

9.AUX : It can insert an audio cable with a 3.5mm stereo plug to connect external audio sources.

10.USB : Connect an external USB device to play the audio files in the device.

Product Parameters

Product name: SD-P12 Portable Speaker

Product model: SD-P12

Wireless version: 5.3

Transmission distance: ≥10M

Frequency response: 65Hz-20kHz

SNR: ≥88dB

Rated power: 15W+5W

Battery capacity: 7.4V/2000mAh

Input: 5V=1A/2A

Play time: 4h

Standby time: 300days

Charging time: 3h

Net weigh: 640G

Product size: 174x84x70mm

Driver unti: 48x90mm+40.8x 51.2mm

SHIDU After sales service:

If you have any questions, please feel free to contact us, we will try our best to provide best service.

WWW.10shidu.com Email: service@ 10shidu.com