

注意：
本手册描述的产品及其附件的某些特征和功能，仅供参考。
十度数码科技保留随时修改本手册中任何信息的权利，无需进行任何提前通知且不承担任何责任。

无担保声明：
本手册中的内容，除非适用法律要求，十度数码科技对本手册中的所有内容不提供任何明示或暗示的保证。
在法律允许的范围内，十度数码科技在任何情况下，都不对因使用本手册相关内容而产生的任何特殊的、附带的、间接的、继发性的损害进行赔偿，也不对任何利润、数据、商誉或可预期的损失进行赔偿。

进出口管制：
若需将此产品手册中描述的产品出口、再出口、或者进口，您应遵守适用的进出口管制法律法规。

深圳市十度数码科技有限公司 地址:深圳市宝安区新安和兴工业园2区A9栋十度科技园
Shenzhen SHIDU Digital Co. Ltd 电话:0755-21635866 传真:0755-29105099
全国服务热线: **4008 939 488**
官方网站: **WWW.10SHIDU.COM**

本说明书所有产品图片及文字功能已经详细校对，如出现印刷错误，本公司不承担任何此产生的后果，产品图片及详细功能参数请以实物为准。
“SHIDU”“十度”“ID”均已注册商標，受知识产权保护，未经本公司允许不得转载、违者必究。
本公司保留产品更改及回收的权利，届时恕不另行通知，在法律允许范围内，恕不解释和召回所有十度数码科技有限公司所有。

Please read the instructions carefully before using it.

Note:
Before turn on the amplifier, ensure that the MIC don't point at the amplifier, this will eliminate any annoyance associated with howling. For ensure better amplification, aim at the headset MIC capsule when speaking, and keep the distance between the voice amplifier and the MIC more than 60cm to avoid howling. Simply tucking the speaker around waist, and mounting head-phone over head can help achieve the required distance.

Features:

- SHIDU patented appearance.
- Adopt 3.5 inch Hi Fi double magnetic big-size trumpet, up to 25W.
- Support Bluetooth function, which can playing audio files in mobile, tablet PC.
- Built-in 2pcs * 3.7V/2600mAh Lithium battery.
- Support TF card/USB flash drive play music.
- Support double wireless microphone speake at the same time.

Technical Parameters:

Power output:	25W	Frequency response:	80Hz-18KHz
Output impedance:	4Ω	Working temperature:	-10°C-45°C
Recharging voltage:	DC 9V 1.2A	Amplification-use time:	8-10 hours
Music-use time:	6-8 hours	Charging time:	3-5 hours

Structure Instruction:

- Power switch:** Long press "⏻" to turn on, then the red light will on all the time; in "power on" status, long press "⏻" to turn off, then the red light will go out.
- Mode:** Short press "M" key to choose Bluetooth / USB flash drive play / TF card play / AUX mode.
- Play/Pause:** In music playing mode, short press it to pause, short press it again to play.

- Bluetooth button:** Long press this button in Bluetooth mode to disconnect the current Bluetooth, and press this button in other modes for one click Bluetooth.
- Next / fast forward:** When playing music short press "⏭" means next song; long press means fast forward. (Note: in Bluetooth mode, long press "⏭" not support fast forward)
- Previous / fast backward:** When playing music short press "⏮" means previous song; long press means fast backward. (Note: in Bluetooth mode, long press "⏮" not support fast backward)
- Volume +:** Short press "+" means increase volume one by one while long press means increase the volume in a fast way.
- Volume -:** Short press "-" means decrease volume one by one while long press means decrease the volume in a fast way.
- Battery capacity display:** In the "power on" status, short press any key can display the current battery level.
- Power and UHF pairing indicator**
- Ø3.5mm Microphone Jack:** Note: This voice amplifier support wired microphone, you can insert the wired microphone in the standard package and realize to amplify the voice.
- Ø3.5mm Aux In**
- DC 9V charging slot**

14.TF card: support various audio formats: MP3, WMA, WAV, APE & FLAC.

15.U disk: support various audio formats: MP3, WMA, WAV, APE & FLAC.

16.Straps hooks

17.Battery cover

Charge the amplifier:

The first frame of battery icon "⚡" is keeping flash during using means it's low battery and need to be charged. Please use DC 9V power charger, the other end connects with the power supply AC 110-220V. The battery icon will flash from first frame to fourth frame when charging, and the four frames of battery icon light on means fully charged.

Note: We suggest fully recharge the amplifier before you using it at the first time.

Bluetooth function:

Please pair with your Bluetooth device as follows:

Step 1: Turn on the speaker get into Bluetooth mode or switch to Bluetooth mode. (It is Bluetooth mode by default once power on.)

Step 2: Turn on your Bluetooth device, scan and search for "SD-S92", click "SD-S92" and successfully connected with a voice prompt: "Bluetooth is connected".

TF card/USB flash drive play:

Insert the TF card / USB flash drive as showed on the amplifier correctly, then press "M" key to switch to TF card / USB flash drive mode, and you can play the audio files in the TF card / USB flash drive.

2.4G Wireless microphone instruction:

- Power on/off:** Press the "⏻" for 3 seconds to turn it on, the green indicator will turn on. Press it again for 3 seconds to turn it off, the green indicator will go out.
- Manual pairing:** (This operation is used for microphone is no sound)
 - Step 1:** Turn on the speaker, When the screen displays 00:00, press and hold the "M" key for 3 seconds to enter the wireless pairing state.
 - Step 2:** Turn on the 2.4G wireless microphone, long press "⏻" for 3 seconds, The blue indicator light stops flashing, indicating that pairing is successful and you can try speaking.

- Volume control:** if speaker howling or in a small volume, adjust the volume by pressing "+" or "-" on the 2.4G wireless microphone.
- Microphone charging:** When the microphone's green indicator light flashes, it means low battery. Please turn it off and charge through Type-c charging cable with DC 5V adapter. The red indicator light will be on all the time when charging, and it will turn off when the mic is fully charged.

Notes:

- The normal charge time is 2 hours, unplug the charger as 00:00, press and hold the "M" key for 3 seconds to enter the wireless pairing state.
- Fully charge before first use of the microphone to ensure best results.
- Turn off the 2.4G wireless microphone when not in use.

Solve some normal problems by yourself:

- Turn on the power switch, but the amplifier has no sound.**
A. The LED is not light: it means low power and you should charge the amplifier.
B. Please confirm whether the wireless microphone has been paired with the amplifier successfully or not.
Pair the UHF frequency point manually again if necessary.
- Pair again the signal frequency of UHF wireless microphone:**
A. If there will be a disturbance when you are using several UHF wireless devices in a close range, please pair again the signal frequency of amplifiers.
B. Please pair again the signal frequency of amplifier when the wireless microphone is broken down & renewed or you want to use the two pairs at the same time.
- The voice amplifier has distinct howling:**
A. Wear the microphones correctly: put the microphone in front of the mouth; and keep the distance between amplifier and microphone about 60-70CM.
B. In a small room, please turn down the volume properly to avoid howling.

SHIDU After sales service:

If you have any questions, please feel free to contact us, we will try our best to provide best service.
www.10shidu.com Email: service@10shidu.com

十度音响

扩音器

使用说明
USER MANUAL

关注十度微信公众号
回复型号“S92 2.4G无线版”
获取产品使用说明书

安全警告:

- 请勿将产品及配件靠近火源或任何过热的环境中。
- 请勿将产品及配件接触水及湿气，不要在靠近水的地方使用本设备，也不要将产品浸入任何液体中，避免产品及配件受到水滴或水蒸。
- 请勿自行打开或任意拆解、维修电池组件，如果电池更换不当会有爆炸危险，严禁将电池投入水、火中或靠近任何过热的环境中。
- 本产品由外接电源适配器(9V 1.2A电源)充电后使用，充电后可方便的通过拔掉电源适配器插头断开电网电源。
- 当用户暂不使用本产品时，请将产品电源开关旋转至关闭状态关闭电源(参见产品操控示意图)，避免电池电量的流失。
- 当禁止使用无线设备或设备的使用会引起电子设备的干扰与安全隐患时，请关闭本产品。
- 在易燃易爆区域，请关闭本产品，并遵守相关标示说明，以免引起爆炸或火灾。易燃易爆区域包括但不限于：加油站、易燃或化工品运输及储存设施、有爆炸危险标志的区域，有“关掉双向无线电设备”标志的区域。
- 乘坐飞机时，请遵守航空公司有关法规和条例，在飞机起飞前关闭本产品，以免造成安全隐患。

产品特点:

- 2.4G无线扩音技术
- 采用3.5寸双音圈高磁高保真喇叭，功率可达25W
- 专利外观，人体工学设计，精美、大气
- 采用十度原声扩音电声系统，扩音声音传输真实、稳定
- 蓝牙5.0云控，支持网络同步教材、音乐在线播放
- 支持卡拉OK同步K歌
- 7.4V大容量锂电池，精工智能保护板
- 音频解码技术，支持TF卡、U盘
- 配备十度专用原声麦克风，高保真原声扩音

数据参数:

输出功率	25W	频率响应	80Hz-18KHz
喇叭阻抗	4Ω	工作温度	-10°C-45°C
充电电压	DC 9V 1.2A	使用扩音时间	8-10小时
使用音乐时间	6-8小时	充电时间	3-5小时

注意:因本机为大功率扩音器,在小面积教室或会场使用时好,请在插入麦克风前将音量调节至最小位置,以免声音过大,造成回声、啸叫,插入麦克风后根据自己所在的场地面积进行音量微调,达到最佳扩音效果。

主机操控示意图:

- 电源开关键:** 长按"⏻"键为开机,开机后红色电源指示灯亮;在开机状态下,长按"⏻"键为关机,关机后红色电源指示灯熄灭。
- 模式切换键:** 可通过短按"M"键进行模式切换,U盘模式、TF卡模式、AUX模式、蓝牙模式。
- 播放暂停键:** 在读卡模式或蓝牙模式时,短按"⏮"键为暂停,再次短按为播放。
- 蓝牙按键:** 在蓝牙模式下长按此按键,为断开当前蓝牙,在其他模式下按此按键,为一键蓝牙。
- 下一曲快速键:** 在读卡模式或蓝牙模式时,短按"⏮"键为下一曲;在读卡模式下,长按为快速;在(蓝牙模式时,长按"⏮"键不支持快速)
- 上一曲快速键:** 在读卡模式或蓝牙模式时,短按"⏭"键为上一曲;在读卡模式下,长按为快速;在(蓝牙模式时,长按"⏭"键不支持快速)
- 音量加:** 短按"+"键为单档音量加,长按为快速音量加。
- 音量减:** 短按"-"键为单档音量减,长按为快速音量减。
- 电量显示图标:** 在开机状态下,短按任何按键可显示当前电量。
- 电源指示灯**

11. MIC插口: 有线麦克风输入
注:本机支持有线麦克风输入功能;可通过随机配送的有线麦克风与主机"MIC"接口连接,直接进行有线扩音模式。

12. AUX插口: 外接音源输入

13. DC9V充电插口

14. TF卡卡槽: 支持MP3、WMA、WAV、APE、FLAC多种格式播放。

- U盘插口:支持MP3、WMA、WAV、APE、FLAC多种格式播放。(仅限数据传输读取U盘数据)
- 背带挂扣
- 电池盖

为主机充电:

在使用过程中,当电池图标"⚡"第一格不停闪烁时,表示当前电量不足,请及时充电。将随机赠送的DC9V充电器接头连接主机DC9V插口;再接驳电源(220V)插座充电;充电时电池符号从第一格到第4格递进式来回闪烁,充满电时电池符号4格全亮。

注意:

- 第一次使用主机时,电池有小部分电量,但为了达到最好的效果,建议先充满电再使用。
- 当主机电池电量耗尽再进行充电时,电池图标需5-30分钟进入充电闪烁状态。
- 充完电后可方便的通过拔掉电源适配器插头断开电网电源。

无线蓝牙操作说明:

首次使用本机时,需与手机或蓝牙设备配对连接,步骤如下:

第1步: 长按"⏻"键开机,按"M"键切换至蓝牙模式。
第2步: 打开手机,进入手机的"设置"菜单,找到蓝牙功能选项,打开手机的蓝牙功能,点"扫描"按钮,待搜索到"SD-S92",点击"SD-S92"连接即可连接,成功的同时手机会提示配对成功。
第3步: 配对成功后,即可通过手机播放教学教材、培训资料、歌曲播放等。同时也可与无线麦克风配合使用实现实时配音直播、同步K歌等功能。

2.4G无线麦克风使用说明:

2.4G无线麦克风/关机: 长按"⏻"3秒绿色指示灯亮,表示已开机;再次长按"⏻"3秒绿色指示灯熄灭,表示已关机。(此操作方法运用于麦克风无声时手动配对)

打开主机,红色电源指示灯常亮时,长按"M"键3秒进入无线配对状态,再把2.4G无线麦克风开机,长按"⏻"键3秒,蓝色指示灯停止闪烁表示已配对成功可以试讲话。

2.4G无线麦克风音量调节: 在使用时如果有啸叫声或2.4G无线麦克风音量小,调节2.4G无线麦克风的音量 "-"键是音量减,音量 "+"键是音量加。

2.4G无线麦克风充电: 2.4G无线麦克风在工作时出现绿色指示灯不停的闪烁时,表示电池电量需要充电,请将2.4G无线麦克风电源关闭后,将2.4G无线麦克风DC 5V接口连接数据线TYPE-C接头,另一端数据线USB接头与DC 5V的USB电源接口连接;充电时2.4G无线麦克风红色指示灯长亮,充满电后红色指示灯熄灭。

注意:

- 正常充电时间约2小时;
- 第一次使用2.4G无线麦克风时,电池有小部分电量,但为了达到最佳扩音效果,请先充满电再使用。
- 充完电后可方便的通过拔掉电源适配器插头断开电网电源。

产品使用注意事项:

- 为了达到话筒扩音最佳效果,请将咪头放置嘴正前方1-2CM处对准咪头处发音,若有啸叫,可适当调小音量或将咪头与咪头的距离稍微拉开,以防互相干扰;
- 尽量避免频繁拔插麦克风插口,以免造成插口松动而引起接触不良,不可将话筒和音源插错;
- 为保证锂电池使用寿命,建议使用充完再充电,频繁充电将加速电池芯片老化,长时间不用时应每隔两个月充一次电;
- 因喇叭磁性较强,不可将机器和银行卡等带磁性的东西放在一起,以免造成失磁而带来不必要的麻烦;
- 本产品所有配件皆按本机工作需要设计,如需更换配件尽量使用本产品原装配件,以达到最佳工作状态;
- 本产品 在充电和正常使用过程中可能会轻微发热,这属于正常现象;
- 请使用防静电软布来清洁擦拭本产品。在清洁本产品时请先关闭电源开关,并断开所有外部连接。请勿用化学物质擦拭(如:酒精、苯等化学试剂或有磨砂性的清洁擦拭剂);
- 请勿摔落、抛掷或者踩踏本产品,请勿擅自拆解本产品,否则不能享受本公司的免费保修服务。
- 符合"微功率短距离无线电发射设备目录和技术要求"的具体条款和使用场景,采用的天线类型和性能、控制、调整及开关等使用方法;
- 不得擅自改变使用场景或使用条件,扩大发射频率范围、加大发射功率(包括额外加装射频功率放大器),不得擅自更改发射天线;

- 不得对其他合法的无线电台(站)产生有害干扰,也不得提出免受有害干扰保护;
- 应当承受辐射射频能量的工业、科学及医疗(ISM)应用设备的干扰或其他合法的无线电台(站)干扰;
- 如对其他合法的无线电台(站)产生有害干扰时,应立即停止使用,并采取消除措施后方可继续使用;
- 在航空器和依据法律法规、国家有关规定、标准划设的射电天文台、气象雷达站、卫星地球站(含测控、测距、接收、导航站)等军民用无线电台(站)、机场等的电磁环境保护区域内使用功率设备,应当遵守电磁环境保护及相关行业主管部门的规定;
- 禁止在在以机场跑道中心为圆心、半径5000米的区域内使用各类模型遥控器;
- 微功率设备使用时温度和电压的环境条件。
- 制造型号: P9mini 销售型号: S92 (具体型号以实物为准)

常见问题的自我解决:

- 开关关闭,扩音器没有声音
 - 显示屏不亮, 电池没电, 充电解决;
 - 检查话筒是否插错位置。
- 扩音器有明显啸叫
 - 正确佩戴话筒, 将麦头记号处对准嘴角方向, 麦克风与主机保持60-70CM距离;
 - 空间变小时适当调低音量以减少回声造成啸叫。

产品保修须知:

为了让您更好的享受我公司的各项服务, 请仔细阅读以下内容: 十度数码科技产品的保修服务由全国各地的十度数码授权技术服务中心负责提供。本产品自销售之日起计保修期和“三包”有效期, 在“三包”有效期内, 正常状态下使用本产品而发生故障, 可依据“三包”规定予以维修、更换、退货。在产品保修期内, 可依照本保修条款的内容, 在十度数码授权技术服务中心享受无偿维修服务(随机附件不在保修范围内)。本品保修期限规定为一年。

在保修期(含“三包”有效期)内以下情况将实施有偿维修服务, 同时不享受“三包”服务:

- 不能出示有效保修卡原件和有效发票。
- 购买产品日期、销售单位名称(盖章有效)等项目未能完整填写或涂改保修卡。
- 由于不可抗拒的自然灾害造成的故障、损伤。
- 在运输、装卸过程中造成的故障、损伤。
- 由于未能按照《产品使用说明书》上所写的使用方法和注意事项操作而造成的人为故障。
- 未经本公司授权人员进行的产品拆卸、维修、改装而造成的故障。

需要保修时将机器与本保修卡(原件)及购机凭证(复印件)一起送往十度数码科技有限公司授权技术服务中心, 运输费用由用户承担。

产品保修卡

购买产品时, 请认真填写此卡, 并予以妥善保存。

用户档案

用户姓名	
性别	
通讯地址	
邮编	
联系电话	
购买地点	
购买日期	
品名及规格	
销售单号	
机身编号	
经销商签名	
用户签名	

X